



Articledescription	VA	PU	EAN-Code
Coffee pot 1 0,30 ltr.	019	2	40 03106 785594
Tea pot 1 0,32 ltr.	019	2	40 03106 785624
Sugar bowl 2 0,25 ltr.	019	1	40 03106 785662
Sugar dish 8 cm	019	12	40 03106 785655
Creamer 00 0,03 ltr.	019	12	40 03106 785693
Creamer 0 0,09 ltr.	019	4	40 03106 095778
Creamer 1 0,15 ltr.	019	1	40 03106 785709
Creamer 2 0,25 ltr.	019	1	40 03106 785716
Coffee cup/saucer 1 0,18 ltr.	067	6	40 03106 785884
Coffee cup 1 0,18 ltr.	019	6	40 03106 785907
Coffee saucer 1 16 cm*	067	6	40 03106 785891
Coffee cup/saucer 2 0,16 ltr.	067	6	40 03106 785914
Coffee cup 2 0,16 ltr.	019	6	40 03106 785938
Coffee saucer 2 16 cm*	067	6	40 03106 785921
Mocha cup/saucer 0,09 ltr.	067	6	40 03106 785853
Mocha cup 0,09 ltr.	019	12	40 03106 785877
Mocha saucer 13,4 cm	067	12	40 03106 785860
Breakfast cup/saucer 0,32 ltr.	067	6	40 03106 785969
Breakfast cup 0,32 ltr.	019	6	40 03106 785983
Breakfast saucer 16 cm*	067	6	40 03106 785976
Cup/saucer 0,28 ltr.	019	6	40 03106 095785
Cup 0,28 ltr.	019	6	40 03106 095792
Saucer 16 cm*	019	6	40 03106 095808
American cup/saucer 0,22 ltr.	067	6	40 03106 785945
American cup 0,22 ltr.	019	6	40 03106 786034
American saucer 16 cm*	067	6	40 03106 785952
Jumbo cup non stack. 0,50 ltr.	019	6	40 03106 785723
Coffee cup/s non stack. 0,18 ltr.	067	6	40 03106 785792
Coffee cup non stackable 0,18 ltr.	019	6	40 03106 785815
Coffee saucer non stack. 16 cm*	067	6	40 03106 785808
Mocha cup/s non stack. 0,09 ltr.	067	6	40 03106 785822
Mocha cup non stackable 0,09 ltr.	019	12	40 03106 785846
Mocha saucer non stack. 13,4 cm	067	12	40 03106 785839
Cafet cup/s non stack. 0,22 ltr.	067	6	40 03106 785730
Cafet cup non stackable 0,22 ltr.	019	6	40 03106 785754
Cafet saucer non stack. 16 cm*	067	6	40 03106 785747
Cup/saucer non stack. 0,28 ltr.	019	6	40 03106 095815
Cup non stackable 0,28 ltr.	019	6	40 03106 310321
Saucer non stackable 16 cm*	019	6	40 03106 095822
Amer. cup/s non stack. 0,37 ltr.	067	6	40 03106 785761
American cup non stack. 0,37 ltr.	019	6	40 03106 785785
American saucer non st. 16 cm*	067	6	40 03106 785778
Egg cup/A	067	6	40 03106 785464
Set salt & pepper	019	1	40 03106 785532
Mug with handle 0,25 ltr.	019	6	40 03106 785990

* combi saucer



Articledescription	VA	PU	EAN-Code
Plate flat 33 cm	067	6	40 03106 785235
Plate flat 30 cm	067	6	40 03106 785228
Plate flat 28 cm	067	6	40 03106 785211
Plate flat 26 cm	067	6	40 03106 785204
Plate flat 23 cm	067	6	40 03106 095839
Plate flat 21 cm	067	6	40 03106 785198
Plate flat 17 cm	067	6	40 03106 785181
Pasta plate deep 30 cm	067	2	40 03106 785358
Pasta plate deep 27 cm	067	2	40 03106 785365
Plate deep 23 cm	067	6	40 03106 785242
Salad plate deep 19 cm	067	6	40 03106 785341
Coupsoup 19 cm	067	6	40 03106 785259
Soup cup/saucer 0,27 ltr.	067	6	40 03106 785266
Soup cup 0,27 ltr.	019	6	40 03106 785280
Soup saucer 16 cm*	067	6	40 03106 785273
Tureen 12 pers. 3,20 ltr.	019	1	40 03106 785372
Covered vegetable 2,30 ltr.	019	1	40 03106 785402
Gravy boat 0,50 ltr.	019	2	40 03106 785433
Butter gravy 0,09 ltr.	019	4	40 03106 099448
Butter gravy 0,15 ltr.	019	4	40 03106 785457
Butter pad 5,4 cm	019	2	40 03106 785440
Bowl round 15 cm	067	4	40 03106 785297
Bowl round 18 cm	067	2	40 03106 785303
Bowl round 20 cm	067	2	40 03106 785310
Bowl round 23 cm	067	2	40 03106 785327
Bowl round 25 cm	067	2	40 03106 785334
Platter oval 25 cm	067	2	40 03106 785549
Platter oval 28 cm	067	2	40 03106 785556
Platter oval 31 cm	067	2	40 03106 785563
Platter oval 35 cm	067	2	40 03106 785570
Duo platter 26 cm	067	2	40 03106 785587
Vase	019	2	40 03106 786003
Candlestick	019	2	40 03106 786010
Ash tray 9,5 cm	019	4	40 03106 786027
Bowl 22 5200/1	019	1	40 03106 786041
Bowl 22 5200/2	019	1	40 03106 786058
Bowl 23 5200/3	019	1	40 03106 786065
Bowl 25 5200/4	019	1	40 03106 786072
Serving dish 5100/8	019	2	40 03106 053495
Serving dish 5100/10	019	2	40 03106 055512